

文章编号: 1006-9941(2007)03-0295-02

## Properties of Insensitive Octogen


XU Rui-juan, KANG Bin, HUANG Hui, JIANG Yan, LI Jin-shan  
(Institute of Chemical Materials, CAEP, Mianyang 621900, China)

Crystal quality and morphology can greatly influence the sensitivity and other properties of energetic crystals. Researches show improving crystal quality of RDX/HMX can reduce their sensitivities. So we prepared a kind of insensitive Beta-octogen fine particle (FD-HMX) by a special crystallization process. In this paper, the crystal qualities and properties of FD-HMX were characterized by scanning electron microscope (SEM), laser light scattering, density gradient technique, differential scanning calorimetry (DSC), impact sensitivity test and gap test. Meanwhile FD-HMX was compared with reference commercial grade HMX.


The results show that FD-HMX is much regular and very smooth (Figure 1). It is very transparent and nearly no internal defects as shown in the optical images in a fluid of matching refractive index (Figure 2). The purity of FD-HMX is  $99.6\% \pm 0.5\%$  measured by high performance liquid chromatography (HPLC), and the mean particle size is 14 to 20 microns with narrow size distribution and the particle density of different batches FD-HMX is  $1.9012 - 1.9020 \text{ g} \cdot \text{cm}^{-3}$  which shown in Table 1. And DSC curve of FD-HMX shows that there are two main thermal effects: solid-phase transition and decomposition. FD-HMX decomposition temperature is same as that of commercial grade HMX, while the solid-phase transition temperature is  $202.33 \text{ }^\circ\text{C}$ , which is higher than  $196.31 \text{ }^\circ\text{C}$  of commercial HMX. So it can be concluded that thermal property of FD-HMX is better than that of commercial HMX.

At the final of the experiment, the sensitivities of FD-HMX were measured by GJB772A - 97 standard test methods of method 601. 1 Initiation Probability Test, method 601. 2 Drop - height Test and method 605. 1 GAP

Test. The results (Table 2) indicate FD-HMX has greater drop heights of 72.2 cm with 2 kg dropping weight and lower initiation probabilities of 24% with 10 kg dropping weight than 16.8 cm and 88% of commercial grade HMX. The aluminium gap thickness of PBX based on FD-HMX is 15 mm, which reduces 2 mm comparing with commercial HMX.



(a) commercial HMX



(b) insensitive HMX (FD-HMX)

Fig. 1 SEM photographs of two HMX particles




Fig. 2 Optical microscopy of FD-HMX in a fluid of matching refractive index

Received Date: 2007-02-07; Revised Date: 2007-04-29

Foundation Item: The Foundation of CAEP 2004Z0503 and 20060538

Biography: XU Rui-juan (1973 - ), female, assistant research fellow, research field: energetic materials. e-mail: xuruijuan\_xu@163.com

**Table 1 Particle size and density of two HMX particles**

		different batches FD-HMX						commercial HMX
		1	2	3	6	7	8	
particle size/ $\mu\text{m}$	size distribution	4 - 40	4 - 40	4 - 40	4 - 40	4 - 40	4 - 40	1 - 100
	$d_{50}$	14	13	18	15	16	17	19
	$d_{90}$	23	21	36	33	33	29	62
particle density	density	1.9012	1.9013	1.9011	1.9008	1.9012	1.9018	1.8979
density / $\text{g} \cdot \text{cm}^{-3}$	distribution	~	~	~	~	~	~	~
	mean	1.9020	1.9018	1.9017	1.9015	1.9019	1.9022	1.8994
	density ( $\pm 0.0005$ )	1.9018	1.9015	1.9014	1.9012	1.9018	1.9020	1.8994

Note:  $d_{50}$  is the particle size of 50% of total volume,  $d_{90}$  is the particle size of 90% of total volume.

**Table 2 Sensitivities of two HMX particles**

	commercial HMX	FD-HMX	remarks
explosive probability 0.95 (Pi, Pu)	88(0.69, 0.98)	32(0.15, 0.54) batch 1 24(0.09, 0.45) batch 2	sample 50 mg hammer 10 kg drop 25 cm
drop height $H_{50}$ /cm	16.8 $\pm$ 0.1	72.2 $\pm$ 0.1 batch 1 * 46 $\pm$ 0.1 batch 2	sample 35 mg hammer 2 kg * hammer 5 kg
gap thickness/mm	17.0 $\pm$ 0.5	15.0 $\pm$ 0.5	aluminium gap $\Phi$ 20 mm charge HMX/binder 88/12

Note: 0.95 (Pi, Pu) is confidence interval at 0.95 confidence level.

**Key words:** analytical chemistry; insensitive HMX; crystal quality; sensitivity

**CLC number:** O65; TJ55

(上接 294 页)

In conclusion, a liquid smoke composition which can effectively attenuate IR radiation in 3 - 5  $\mu\text{m}$  and 8 - 14  $\mu\text{m}$  bands is developed. Chamber test results show that the developed composition can effectively attenuate IR radiation. The transmittance of formed smoke is 11.7% in 3 - 5  $\mu\text{m}$  bands and 3.9% in 8 - 14  $\mu\text{m}$  bands respectively. It can also totally obscure IR thermal imaging system as long as 30 s.

**Key words:** pyrotechnic; liquid; infrared countermeasure; smoke composition; smokescreen

**CLC number:** TQ567.5




Fig. 1 Curves of IR spectrum transmittance at 0.5 min and 1.5 min